Table Of Contents

SECTION 1: OVERVIEW 1-1

SECTION 2: SPECIFICATIONS 2-1

SECTION 3: PREVENTATIVE MAINTENANCE 3-1

SECTION 4: COMPONENT LOCATION 4-1

SECTION 5: INSTALLATION & ADJUSTMENT PROCEDURES
1. Envelope Feeder Installation Guide 5-1
2. Mounting Bracket Adjustment..... 5-2
3. Setting the Stripper Height 5-3
4. Setting the Envelope Guides 5-4
5. Envelope Belt Guide Adjustment..... 5-4
6. Metal Transport Rollers 5-5
7. Side to Side Registration 5-5

SECTION 6: WIRING DIAGRAMS
1. Point to Point 6-1
2. Interface Cable Connection 6-2
3. Interface Cable 6-3

SECTION 7: TROUBLESHOOTING.....7-1

SECTION 8: PARTS LAYOUT
1. Electrical 8-1
2. Mechanical 8-2
3. ConsoleAR8000 envelope Feeder 8-3